We are here to help. Feel free to contact us with questions or to provide feedback.

For additional information, please visit the FAQ section of our website at www.acanac.com. To provide feedback, please submit a customer review via our website or our Facebook page. For other questions, please call our Customer Experience team at 1-866-281-3538. You can also receive Technical Support at the same number – you can also send us an email at technical.support@acanac.com.



Acanac

t's good to be here





High Speed DSL Internet Setup Guide






Thank You for choosing Acanac

In order to ensure the smooth setup of your Acanac High Speed DSL Internet service, please follow the easy steps laid out in this guide.

The setup kit for your High Speed DSL service should contain the following items: Power Lanz Lanz Lans Lans WIAN WPS USB DSL Internet

Modem SR505N* and power supply



For customers with a landline phone, your setup kit will also include a splitter and filter. Please follow special instructions in Step 1 and Step 4.

Phone

Cable (1)

Please note that the modem shown is for the purposes of illustrating the setup process and may differ from your device




Before beginning the setup process, please ensure that all of your equipment is turned off.



Using the phone cable provided in your installation kit, connect the grey DSL port located on the back of the modem SR505N to your phone jack.


For customers with a landline phone, connect the grey DSL port located on the back of the





STEP 2

Using the Ethernet cable provided, connect the modem SR505N LAN port to your laptop (or the WAN port of your router if you would like a network setup).



Back of Modem SR505N

Power Jani Lang Lang Land WLAN WPS USB DSL Internet




STEP 3


Please wait 2 minutes for the modem to boot-up. The POWER and DSL lights should become solid green. The INTERNET and the LAN1 lights should become solid or blinking green. If you do not see the mentioned lights, please repeat steps 1 and 2. Ensure that the switch button, located in the back of the modem, is depressed.

Front of Modem SR505N



For customers with a landline phone, the filter(s) must be connected between your phones and their corresponding phone jacks, as illustrated below.





You may now turn all your devices back on.



DSL MODEM SR505N LIGHTS

LIGHTS	READ
Power	Solid Green
LAN1-4	Solid or Blinking Green (Off if unused)
WLAN	Solid Green if WiFi enabled (Off if unused)
DSL	Solid Green
Internet	Solid or Blinking Green

